



HANDING OF HOT WATER UNITS

**THE UNIT WIDTH RUNS PARALLEL TO THE BALLVALVE ARM
BALLVALVE CONNECTION DETERMINES THE HANDING**

Left Hand Unit



Right Hand Unit



**THE BALLVALVE CONNECTION IS ALWAYS ON THE DEPTH.
THE FEED CISTERN IS ALWAYS ON THE FRONT OF THE UNIT.
OTHER FITTINGS ARE GENERALLY ON LEFT- OR RIGHT-HAND SIDE, OR ON BOTTOM.**